


AUDIOVOX™

High Fidelity Compact Disc Players CDA-475 Instruction Manual



Audiovox Specialized Applications, LLC
23319 Cooper Drive
Elkhart, IN 46514
(219) 264-3135

Product Description-----


The CDA-475 is an automotive audio compact disc player. Both the form and function have been chosen to compliment the Audiovox® wall mount radio product line. It is cosmetically similar to the Audiovox® AWM-500 series and AWM-400 series radios. However, it can also be used with any audio system with line level inputs.

The CDA-475 provides the following features:

- Illuminated controls and LCD display
- Skip resistant disc mechanism
- Styling compliments Audiovox® AWM-500 series and AWM-400 series radios
- LCD display shows track number and elapsed time
- Shallow mounting depth (only 6 inches)
- Line level audio inputs
- Quick disconnect power connector

Mounting Requirements and Cutout Dimensions


Overall Dimensions



Mounting Hole Dimensions



Operation-----



Note: CDA-475 must be connected to a radio with aux input. Radio must be turned on and switched to the aux mode of operation.

- 1) Eject Button:** Pressing this button will eject the CD during play. If player is off and CD is loaded, pressing eject will eject the CD after a short pause.
- 2) Power:** Pressing this button will turn off unit during play or power the unit if it is in the "off" state.
- 3) Play/Pause:** Press this button to pause the CD on the current track. Pressing again will resume play.
- 4) Repeat:** Pressing this button while CD is playing causes the unit to repeat the current track, pressing again will cause entire CD to be repeated. A third press deactivates repeat mode.
- 5) Track ▼ /Track ▲:** Pressing the respective side of this button will change to the next track. The first track can be selected from the last by pressing the track ▲ side. The last track can be selected from the first by pressing the track ▼ side. Track indicator will show segments from 1-15, and display will show elapsed track time. Track will also act as a "Music Search" when either side is pressed and held.
- 6) LCD Display:** Display is illuminated while CD player is on. Display shows track number during PLAY, EJECT, STOP, OPEN, PAUSE, AND "RPT." LCD display will be blank with no CD inserted.

Accessory List-----

Description	Part Number
AVT-988 9" Color Television with Remote (12V)	AVT988
AVT-597 5" Color Television with Remote (12V)	AVT597
AVT-1498 13" Color Television with Remote (12V)	AVT1498
AVP-7000 Video Cassette Player (12V)	AVP7000
AVP-7285 Video cassette Player (12V)	AVP7285
Wireless Headphone Kit: Includes 2 sets Wireless Headphones and Transmitter	WRFKIT1
BPA-501-12 4 Amp Adapter for use with AVT-988 9" and AVT-1498 13" Televisions	0891412
AC2A- 2 Amp Adapter for use with AVT-597 5" TV and AVP-7000 Video Cassette Player	0891436
Unified Remote Control	0892325
VAC-21- 12 Volt Corded Vacuum	VAC21
AVF-1 12 Volt Rechargeable Flashlight	AVF1
HP-175 Headphones with Pivoting Ear Cup	HP175
HP-275 Headphones with Volume Control on Cord	HP275
HP-375 Studio Quality Headphones	HP375

Unlike household electronics, all of our products have been specifically designed and tested for the mobile environment and are only available through ASA. To order any of these products, please contact Audiovox Specialized Applications at www.asaelectronics.com or 800-688-3135.

